


Foundation for the - spirit level – when installing water tables or large pond / fountain



Place if necessary. a drain pipe as transit to further placed electrical outlet: 230V AC / 50Hz

>>> Never cut the electrical connector from the pump cord <<<

NO electricity connection under the water container / water table, pump cord is more than 6 metres outside the water tank. This give sufficient possibilities.